
Meridian 1

Automatic Call Distribution

Management commands and reports

Document Number: 553-2671-112

Document Release: Standard 4.00

Date: August 1996

© 1993, 1996

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

August 1996

Standard, Release 4.00. This document is reissued for X11 Release 22.0x.

December 1995

Standard, Release 3.00. This document is reissued to include editorial changes. Due to the extent of the changes, revision bars are not used.

December 1994

Standard, Release 2.00. This document is reissued to include editorial changes and indexing. Due to the extent of the changes, revision bars are not used.

August 1993

Standard, Release 1.00. This document includes all information from and replaces documents 553-2671-102 and 553-2671-103. Changes for X11 Release 19 only are noted with revision bars in the margins.

Contents

Introduction	1
Document overview	1
Operational overview	2
Other documentation	2
Accessing the command mode	3
Management reporting commands	4
Management command conventions	7
Enhanced ACD Routing (EAR)	7
Customer Controlled Routing (CCR)	9
CCR Management Reporting	10
Agent ID option	10
ACD set login	11
500/2500 telephone login protocols	11
Data Agent login	12
ACD telephone logout	12
Data Agent logout	12
Walkaway/Return	13
Agents using DN keys	14
Alternate Call Answer	14
Load management commands	15
Set Controlled mode (CNTL)	15
Set Default ACD DN (DFDN)	16
Query current options (POPT)	17

Query current parameters (PPAR)	18
Select Route and Trunk Assignment (SRTA)	19
Select trunk Priority Assignment (SPRI)	19
Select Agent Position Assignment (SAPA)	20
Select Agent to Supervisor Assignment (SATS)	21
First RAN Route Assignment (FRRT)	22
First RAN Route Time (FRTT)	23
Second RAN Route Assignment (SRRT)	23
Second RAN Route Time Option (SRTO)	24
Night RAN Route Assignment (NRRT)	24
Night Forwarding number assignment (NITE)	25
Automatic Overflow Target DN (SQ01, SQ02, SQ03)	26
Automatic Overflow thresholds (TLDA, TLDB, TLDC)	27
Time Overflow threshold (TLDD)	28
Setting the Interflow DN (IFDN)	29
Telephone Service Factor time (TSF)	29
Set Agent Priority (SAGP)	30
List Agent Position Assignment (LAPA)	30
List Agent Priority (LAGP)	31
Enable Call Force (FORC)	32
Enable Flexible Call Force (FCFT)	33
Print CDN Parameters and Options (PCPO)	34
Set the Call Ceiling (CEIL)	35
Display Routing Tables (DSPL)	35
Management reporting	37
Obtaining supervisor reports	37
Report Control	38
Warning messages	40
Report data	42
Report 1: Agent Group Report	53

Report 2: Queue Report	57
Report 3: RAN Report	66
Report 4: Agent Position Report	68
Ongoing Status Display	70
Short Reports	75
Enhanced daily totals	76
Daily system totals	79